



# **Pulsonix Design System**

## **Library Integration Toolkit**



## Copyright Notice

Copyright © WestDev Ltd. 2000-2009

Pulsonix is a Trademark of WestDev Ltd. All rights reserved. E&OE

Copyright in the whole and every part of this software and manual belongs to WestDev Ltd. and may not be used, sold, transferred, copied or reproduced in whole or in part in any manner or in any media to any person, without the prior written consent of WestDev Ltd. If you use this manual you do so at your own risk and on the understanding that neither WestDev Ltd. nor associated companies shall be liable for any loss or damage of any kind.

WestDev Ltd. does not warrant that the software package will function properly in every hardware software environment.

Although WestDev Ltd. has tested the software and reviewed the documentation, WestDev Ltd. makes no warranty or representation, either express or implied, with respect to this software or documentation, their quality, performance, merchantability, or fitness for a particular purpose. This software and documentation are licensed 'as is', and you the licensee, by making use thereof, are assuming the entire risk as to their quality and performance.

In no event will WestDev Ltd. be liable for direct, indirect, special, incidental, or consequential damage arising out of the use or inability to use the software or documentation, even if advised of the possibility of such damages.

WestDev Ltd. reserves the right to alter, modify, correct and upgrade our software programs and publications without notice and without incurring liability.

Microsoft, Windows, Windows NT and Intellimouse are either registered trademarks or trademarks of Microsoft Corporation.

All other trademarks are acknowledged to their respective owners.

Pulsonix, a division of WestDev Ltd.

Printed in the UK.

Issue date: 09/06/09

### **Pulsonix**

Oak Lane  
Bredon, Tewkesbury  
Glos, GL20 7LR  
United Kingdom

Phone +44 (0)1684 773881

Fax +44 (0)1684 773664

Email [info@pulsonix.com](mailto:info@pulsonix.com)

Web [www.pulsonix.com](http://www.pulsonix.com)



# Contents

<b>CONTENTS.....</b>	<b>5</b>
<b>CHAPTER 1. GETTING STARTED .....</b>	<b>7</b>
Introduction.....	7
The contents of the Toolkit.....	7
Licensing the Toolkit.....	7
Creating library Integration files .....	7
Using library integration files .....	8
<b>CHAPTER 2. SYMBOL FILES .....</b>	<b>9</b>
General commands.....	9
Header section commands .....	9
Symbol section commands .....	9
Generic commands.....	9
Segmented Rectangle symbols .....	12
<b>CHAPTER 3. FOOTPRINT FILES .....</b>	<b>13</b>
General commands.....	13
Header section commands .....	13
Footprint section commands .....	13
Generic commands.....	13
Axial footprints.....	18
PGA footprints.....	18
QUAD footprints .....	18
RADIAL footprints.....	18
Standard parameter types .....	19
<b>CHAPTER 4. PART FILES.....</b>	<b>21</b>
General commands.....	21
Header section commands .....	21
Part section commands .....	21
Finding or creating Parts .....	21
Other commands.....	22
<b>APPENDIX A. SAMPLE FILES .....</b>	<b>27</b>
Symbol Files .....	27
Footprint Files.....	27
Through-hole DIP.....	27
Surface-mount PLCC.....	28
Use of ADDPAD command .....	29
Parts Files .....	29
Normal use to create new parts.....	29
Use of ADDPINATTR, ADDUNGATEDPINS and ++ commands .....	30
<b>APPENDIX B. CHANGE HISTORY .....</b>	<b>31</b>
Issue 30-Apr-09 [Pulsonix 6.0] .....	31

## 6 Contents

---

Issue 20-Oct-08 [Pulsonix 5.1].....	31
Issue 08-May-08 [Pulsonix 5.0].....	31
Issue 27-Mar-08.....	31
Issue 18-Feb-04.....	31
Issue 01-Sep-03.....	32
Issue 02-June-03.....	32
Issue 26-Feb-03.....	32
Issue 09-Sep-02.....	32
Issue 21-Aug-02.....	32
Issue 06-Aug-02.....	32
<b>INDEX .....</b>	<b>33</b>

# Chapter 1. Getting Started

## Introduction

The Library Integration toolkit provides you with the ability to create Pulsonix library (Schematic Symbol, PCB Footprint and Part) items from your own data sources. This might include, for example, importing data from another CAD system, or generating footprints from information retrieved from the Internet.

The files are of a fixed ASCII format as defined in this specification and are imported using a licensed interface mechanism.

## The contents of the Toolkit

The Toolkit consists of:

- This documentation (the import file specification).
- Importers to read library integration files.

## Licensing the Toolkit

The license for this option is shown in the License Manager dialog as **Library Integration Toolkit**. There is no charge for this option.

In addition, creation of bond pads and wires in footprints is controlled by the availability of another license, which appears in the License Manager dialog as **Chip Packaging Toolkit**. Without this license, bond pad and wire commands will be ignored.

## Creating library Integration files

The commands available for use in a library integration file generally follow the 'controls' presented on the pages of the corresponding Pulsonix Library Wizard, and the resulting library items should correspond to those that can be generated using the same values in the Wizard.

Integration files are processed sequentially (from start to finish), and – except for the **FORMAT command** - any of the commands listed in the reference sections may appear anywhere in the file. However, for ease of understanding the commands are separated into those that generally only appear at the start of the file and those that are used to generate the actual footprints.

The positioning and ordering of commands in the file is not generally critical. Any side-effects for particular commands are mentioned in the description for those commands.

Each line of a integration file contains a keyword, followed by one or more parameters (depending on the keyword), separated from each other by commas. Blank lines, and

any lines starting with semi-colon, are ignored. Text (e.g. name) fields may be enclosed in double quotes if desired.

Some commands are applicable only in certain contexts, for example only for certain footprint types. The toolkit does not context-check the commands, so specifying commands that are not applicable may either have no effect, or cause unpredictable results. If commands are specified as they would be entered interactively through the corresponding Wizard, then this should give the desired result. The same applies to range checking, for example on the number of pads on a footprint.

### Using library integration files

Library integration files are loaded into Pulsonix through the Import option on the relevant page of the Libraries dialog.

For example, to import a footprint integration file, open the Libraries dialog and go to the **Footprints** tab. Choose the library to which the generated footprints should be written. Click the **Import** button, browse to the desired integration file, and click on **Open**. The file will be loaded and processed to generate the specified footprints.

## Chapter 2. Symbol Files

### General commands

# Text\_here

The hash (#) character can be used at the start of any new line to write a comment. It should be added to every line which needs a comment. It can be used at any point in the SGF file.

### Header section commands

FORMAT,SGF,1

The first line of the file should contain this command, which specifies that this is a symbol library toolkit file, and also gives the format version number (currently version 1).

FILE,filename

Include another integration file. Each line in the specified file is processed, then processing of the current file resumes.

TYPE,symbol\_type

Specify the type of symbol to create. These values correspond to those available interactively through the Symbol Wizard.

symbol\_type := RECT | SEG | TRI

UNITS,unit,factor,precision

Co-ordinate units.

unit :=	0	inch
	1	thou
	2	metre
	3	millimetre
	4	micron
	5	centimetre

factor := units per base units, generally always 1

precision := number of decimal places

### Symbol section commands

The commands listed here are divided into several sections. Many commands (listed under ‘Generic commands’) are applicable to many or all symbol types, whilst others only really apply to particular types.

#### Generic commands

NAME,symbol\_name

The name by which the symbol is to be known. This command is the one that triggers generation of the symbol and writing it to the library, so positioning of this command in the file is critical to achieving the desired symbols.

BOTTOMPINDIRLEFT, bool

True if the pins on the bottom side are numbered leftwards.

BOTTOMPINORDER, int

The 'side order' for numbering pins on the bottom side of the symbol.

BOTTOMPINS, count

The number of pins on the bottom side.

CLKPIN, size

The size of the clock pin marker.

INVPIN, size

The size of the inverted (not) pin marker.

LEFTPINDIRUP, bool

True if the pins on the left side are numbered upwards.

LEFTPINORDER, int

The 'side order' for numbering pins on the left side of the symbol.

LEFTPINS, count

The number of pins on the left side.

LEGLEN, size

The length of the terminal "legs".

MARKPIN, pin\_number[,type][,CLK]

Adds 'special' marker(s) to specified pin. The available types correspond to those available interactively in the Symbol Wizard. Including the optional field "CLK" will also include a Clock pin marker inside the symbol outline.

pin\_number

pin (terminal) number

type

POLIN | POLOUT | INV

NAMEPOS, name\_pos

Specify the position for the component name.

name\_pos

0

bottom left

1

bottom right

2

top right

3

top left

4

centre

NUMBERSOUTSIDE, bool

Whether or not pin numbers should be placed 'outside' the pins, away from the body of the symbol.

ORIGIN, origin\_pos

The position of the footprint (symbol) origin.

origin\_pos

0

centre

1

pin 1

SPICENAMEPOS, name\_pos

Specify the position for the Spice model name. Values are the same as for the NAMEPOS command.

- PADDIM3,size**  
The size of the third size parameter required for some pad style shapes. This is the thickness for target or cross, the inner size for annulus, and the corner radius for rounded rectangle.
- PADFILLED,bool.**  
Specify whether the pad style for terminals is to be ‘filled’.
- PADLENGTH,size**  
The length for some pad style shapes (rectangle, rounded rectangle, triangle, oval, bullet, pointer, diamond).
- PADPITCH,size**  
The size of the step between adjacent pads.
- PADSHAPE,pad\_shape**  
The shape of the pads. Note that presently only some of the possible pad shapes are supported by the toolkit.  
pad\_shape := DIAMOND | OVAL | RECT | ROUND | ROUNDRECT | SQUARE | CROSS | CHAMFERRECT | BULLET | TRIANGLE | PLUS
- PADSIZE,size**  
The width of pads.
- PADSTYLE,style\_name**  
The name to use for the pad style.
- POLPIN,size**  
The size of the polarity in/out pin marker.
- RIGHTPINDIRUP,bool**  
True if the pins on the right side are numbered upwards.
- RIGHTPINORDER,int**  
The ‘side order’ for numbering pins on the right side of the symbol.
- RIGHTPINS,count**  
The number of pins on the right side.
- SHOWLOGICNAMES,bool**  
Whether or not to set logic names to be visible.
- SHOWPINNAMES,bool**  
Whether or not to set pin names to be visible.
- SYMWIDTH,size**  
The width of the symbol outline (“body”).
- TOPPINDIRLEFT,bool**  
True if the pins on the top side are numbered leftwards.
- TOPPINORDER,int**  
The ‘side order’ for numbering pins on the top side of the symbol.
- TOPPINS,count**  
The number of pins on the top side.

### Segmented Rectangle symbols

SEGMENTS,count  
Number of segments.

SEGLEFTPINS,count  
Number of pins on the left of each segment.

SEGRIGHTPINS,count  
Number of pins on the right of each segment.

## Chapter 3. Footprint Files

### General commands

# Text\_here

The hash (#) character can be used at the start of any new line to write a comment. It should be added to every line which needs a comment. It can be used at any point in the PGF file.

### Header section commands

FORMAT,FGF,1

The first line of the file should contain this command, which specifies that this is a footprint library toolkit file, and also gives the format version number (currently version 1).

TYPE,footprint\_type

Specify the type of footprint to create.

footprint\_type := AXIAL | DIP | PGA | QUAD | RADIAL

UNITS,unit,factor,precision

Co-ordinate units.

unit :=	0	inch
	1	thou
	2	metre
	3	millimetre
	4	micron
	5	centimetre

factor := units per base units, generally always 1

precision := number of decimal places

FILE,filename

Include another footprint integration file. Each line in the specified file is processed, then processing of the current file resumes.

### Footprint section commands

The commands listed here are divided into several sections. Many commands (listed under ‘Generic commands’) are applicable to many or all footprint types, whilst others only really apply to particular types.

#### Generic commands

ADDBONDPAD,x,y,angle

Add a bond pad in a particular position. This command allows you to create bond pads and wires. The co-ordinates supplied are relative to the position of the symbol origin. Each bond pad created (using the bond pad style, see

BONDPAD\* commands) will be wired to the corresponding normal (die) pad using the specified wire style (see WIRE\* commands).

---

*Note: This list of bond pads is only applied to the current footprint; the list is deleted as soon as the current footprint has been generated.*

---

ADDBONDPADREL,dx,dy,angle

Add a bond pad in a particular position relative to the previous bond pad added.

ADDBONDPADSET,count,sx,sy,dx,dy,angle

Add a number of bond pads in specified positions, the equivalent of repeated calls to ADDBONDPAD command.

count := how many bond pads to add  
sx,sy := co-ordinates of first bond pad  
dx,dy := delta “step” between each pad in x & y  
angle := pad angle

ADDBONDPADSETREL,count,dx,dy,angle

Add a number of bond pads in specified positions relative to the previous bond pad added, the equivalent of repeated calls to ADDBONDPADREL command.

count := how many bond pads to add  
dx,dy := delta “step” between each pad in x & y  
angle := pad angle

ADDPAD,x,y

Add a pad in a particular position. This command allows you to specify pad positioning that the footprint integration would not normally create. The co-ordinates supplied are relative to the position of the symbol origin.

---

*Note: This list of ‘irregular’ pads is used in place of (not as well as) the default pads for the footprint type. Also, it is only applied to the current footprint; the list is deleted as soon as the current footprint has been generated.*

---

ADDPADREL,dx,dy

Add a pad in a particular position relative to the previous pad added.

ADDPADSET,count,sx,sy,dx,dy

Add a number of pads in specified positions, the equivalent of repeated calls to ADDPAD command.

count := how many pads to add  
sx,sy := co-ordinates of first pad  
dx,dy := delta “step” between each pad in x & y

ADDPADSETREL,count,dx,dy

Add a number of pads in specified positions relative to the previous pad added, the equivalent of repeated calls to ADDPADREL command.

count := how many pads to add  
dx,dy := delta “step” between each pad in x & y

BONDPADDRILL,size

Bond pad drill diameter.

BONDPADLAYER,layer\_name

Specify the name of the layer on which bond pads should be created. The value for this field is generally one of:

<Through Board>

<Top Side>

<Bottom Side>

BONDPADLENGTH,size

The length for some pad style shapes (rectangle, rounded rectangle, triangle, oval, bullet, pointer, diamond).

BONDPADSHAPE,pad\_shape

The shape of the bond pads. Note that presently only some of the possible pad shapes are supported by the toolkit.

pad\_shape := DIAMOND | OVAL | RECT | ROUND | ROUNDRECT | SQUARE | CROSS | CHAMFERRECT | BULLET | TRIANGLE | PLUS

BONDPADSIZE,size

The width of bond pads.

BONDPADSTYLE,style\_name

The name to use for the bond pad style.

DRILL,size

Pad drill diameter.

FIRSTPIN,pin\_num\_pos

Specify the position for the first pin number.

pin_num_pos :=	0	bottom left
	1	bottom middle
	2	bottom right
	3	right bottom
	4	right middle
	5	right top
	6	top right
	7	top middle
	8	top left
	9	left top
	10	left middle
	11	left bottom

NAME,footprint\_name

The name by which the footprint is to be known. This command is the one that triggers generation of the footprint and writing it to the library, so positioning of this command in the file is critical to achieving the desired footprints.

NAMEPOS,name\_pos

Specify the position for the component name.

name_pos	0	bottom left
	1	bottom right
	2	top right

	3	top left
	4	centre
ORIGIN,origin_pos		
The position of the footprint (symbol) origin.		
origin_pos	0	centre
	1	pin 1
PADCOUNT,count		
The number of pads in the footprint.		
PADDIM3,size		
The size of the third size parameter required for some pad style shapes. This is the thickness for target, the inner size for annulus, and the corner radius for rounded rectangle.		
PADLAYER,layer_name		
Specify the name of the layer on which pads should be created. The value for this field is generally one of:		
	<Through Board>	
	<Top Side>	
	<Bottom Side>	
unless creating die pads for die/bond wiring, in which case this should specify the appropriate wire layer name from your technology file (e.g. Wires Top).		
PADLENGTH,size		
The length for some pad style shapes (rectangle, rounded rectangle, triangle, oval, bullet, pointer, diamond).		
PADPITCH,size		
The size of the step between adjacent pads.		
PADSHAPE,pad_shape		
The shape of the pads. Note that presently only some of the possible pad shapes are supported by the toolkit.		
pad_shape := DIAMOND   OVAL   RECT   ROUND   ROUNDRECT   SQUARE   CROSS   CHAMFERRECT   BULLET   TRIANGLE   PLUS		
PAD1SHAPE,bool,pad_shape		
If true, the first pad on the footprint is created using the specified pad shape. Otherwise, all pads are created using the same basic pad shape.		
PADSIZE,size		
The width of pads.		
PADSTYLE,style_name		
The name to use for the pad style.		
PINORDER,pin_order		
The order in which pins should be numbered.		
pin_order	0	clockwise
	1	counter-clockwise

PLACEBOX,llx,lly,urx,ury

Specify the location of the enclosing box of the placement shape. This box is discarded after each footprint is generated. The co-ordinates supplied are relative to the position of the symbol origin.

PLACECREATE,bool

Whether or not to generate a placement shape.

PLACEGAP,size

The gap between the pad edges and the placement shape.

PLACEISAREA,bool

Whether or not the placement shape is to be created as an Area.

PLACELAYER,layer\_name

The name of the layer on which the placement shape is to be added.

ROWPITCH,size

The distance between rows of pads.

---

*Note: Setting this value also sets the VERTROWPITCH parameter to this size. To specify horizontal and vertical row pitches separately, the HORIZROWPITCH and VERTROWPITCH commands should be used.*

---

SHOWPINNAMES,bool

Whether or not to set pin names to be visible.

SILKCREATE,bool

Whether or not a silkscreen shape should be created.

SILKDOT,bool

Whether or not to add a 'dot' at pad 1 on the silkscreen.

SILKGAP,size

The gap between the pad edges and the silkscreen shape.

SILKLAYER,layer\_name

The name of the layer on which the silkscreen shape should be created.

SILKMITRE,bool

Whether or not the first corner of the silkscreen shape should be mitred.

SILKMITRESIZE,size

The size of the silkscreen corner mitre.

SILKNOTCH,bool

Whether or not the end of the silkscreen shape should be mitred.

SILKNOTCHSIZE,size

The size of the silkscreen notch.

SILKOUTSIDE,bool

Indicates whether the silkscreen shape is outside the pads or inside.

WIRELAYER,layer\_name

The name of the layer on which bond wires should be created.

## 18 Footprint Files

---

WIRESIZE,size  
The size of the line style used for bond wires.

WIRESTYLE,style-name  
The name of the line style for bond wires.

### Axial footprints

AXIALLEGS,bool  
Specify whether or not 'legs' are to be drawn between the component outline 'box' and the pads.

BOXLENGTH,x  
Horizontal length of component outline box.

BOXROUND,bool  
If true, the component outline will have semi-circular ends instead of flat.

BOXWIDTH,y  
Vertical size of component outline box.

### PGA footprints

COLCOUNT,count  
The number of columns.

ROWCOUNT,count  
The number of rows.

STAGGERODD,bool  
Whether or not odd rows of the footprint are 'staggered'.

STAGGERPITCH,size  
The amount by which alternate rows of the footprint are staggered.

### QUAD footprints

HORIZPADCOUNT,count  
The number of pads along the horizontal sides.

HORIZROWPITCH,size  
The distance between the rows of pads on horizontal sides of the footprint.

VERTPADCOUNT,count  
The number of pads along the vertical sides.

VERTROWPITCH,size  
The distance between the rows of pads on vertical sides of the footprint.

### RADIAL footprints

DIAMETER,size  
The radius of the component outline shape.

RADIUS,size

The radius of the component outline shape. This command is provided as an alternative to the DIAMETER command; both commands affect the same underlying value.

STARTANGLE,angle

The angle at which the first pin is positioned relative to the centre of the footprint.

TABANGLE,angle

The angle of the 'tab' on the silkscreen shape.

TABSIZE,size

The size of the 'tab' on the silkscreen shape.

### **Standard parameter types**

angle

Angle as a floating-point number.

bool

Boolean true/false value. Specify Y or y for true, any other value for false.

count

Number of items as a positive integer, generally greater than zero.

size

Item size, width or diameter in current units.

x

X-coordinate in current units.

y

Y-coordinate in current units.



## Chapter 4. Part Files

### General commands

# Text\_here

The hash (#) character can be used at the start of any new line to write a comment. It should be added to every line which needs a comment. It can be used at any point in the PGF file.

### Header section commands

FORMAT,PGF,3

The first line of the file should contain this command, which specifies that this is a part library toolkit file, and also gives the format version number.

The current version number is version 3.

**IMPORTANT:** for format 3 and later, new parts will default to being added together into the same group as they are created. To prevent this, either use format 2, or add the command PARTGROUP,NONE near the start of the file.

FILE,filename

Include another integration file. Each line in the specified file is processed, then processing of the current file resumes.

### Part section commands

#### Finding or creating Parts

ASSOCPART,name[,desc[,family[,namestem]]]

Generate a new Associated part using the supplied parameters.

name := part name  
 desc := optional part description  
 family:= optional part family

FINDPART,name

Find and open an existing part using the supplied name. This is now available for edit (adding attributes to for example).

name := part name

NEWPART,name,desc,mfr,scmsym,[scmsympin],footprint,num\_pins[,pin\_num\_list]

Generate a new part using the supplied parameters.

If specifying pin number entries for ‘multiply mapped’ pins, the entry should be enclosed in double-quotes, for example: 1,2,3,”4,5,6”,10,9,8,7

name := part name  
 desc := optional part description  
 mfr := optional manufacturer name

scmsym :=	the name of the schematic symbol
scmsympins:=	optional, the number of schematic symbol pins
footprint :=	the name of the pcb footprint
num_pins :=	the count of the number of pins
pin_num_list :=	optional comma-separated list of pin numbers

PART,name,description,mfr,footprint,num\_pins

Generate a new part using the supplied parameters, without adding any gates to the part.

name :=	part name
description :=	optional part description
mfr :=	optional manufacturer name
footprint :=	the name of the pcb footprint
num_pins :=	the count of the number of pins

### Other commands

ADDATTR,name,value

Add an attribute to the previously generated part. This command must come after a NEWPART, FINDPART or ADDPART command so that a 'current part' is available to which the attribute can be added.

The following 'special' attribute names are recognised and will be added to the part as the equivalent built-in attributes:

3DPACKAGE  
FAMILY  
HEIGHT  
HYPERLINK  
SPICEDEVICE  
SPICEVALUE  
SPICETEMPLATE  
SPICEFUNCTION  
SPICEPARAMETERS  
SPICEDEFINITION  
SPICETOLERANCE

ADDGATE,scmsym,num\_pins[,pin\_num\_list]

Add a gate to the current part.

If specifying pin number entries for 'multiply mapped' pins, the entry should be enclosed in double-quotes, for example: 1,2,3,"4,5,6",10,9,8,7

scmsym :=	the name of the schematic symbol
num_pins :=	the count of the number of pins on the symbol
pin_num_list :=	optional comma-separated list of pin numbers

ADDPART,name

Generate another part using the given part name, copying all remaining parameters from the previously generated part. This command must come after a

NEWPART or ADDPART command so that a 'current part' is available for the part details.

ADDPARTREP, partrep\_name[, scmsym, num\_pins[, pin\_num\_list]]

Add a part representation and (optionally) its first gate to the current part. Leave the partrep\_name blank to get the current part representation name as defined by the PARTREP command. If not blank, this will update the value of the current part representation name.

If specifying pin number entries for 'multiply mapped' pins, the entry should be enclosed in double-quotes, for example: 1,2,3,"4,5,6",10,9,8,7

partrep_name :=	the name of the part representation
scmsym :=	the name of the schematic symbol
num_pins :=	the count of the number of pins on the symbol
pin_num_list :=	optional comma-separated list of pin numbers

ADDPINATTR, pin\_name, pin\_attr=attr\_value [ , pin\_attr=attr\_value ... ]

Add an attribute or property to a part pin.

pin_name :=	identifies the pin to which attribute applies. If this is * then attribute is applied to all pins that don't have any attributes, logic name or pintype.
pin_attr :=	pin attribute or property name. Pre-defined names are: LOGICNAME, NETNAME, PINTYPE (see below) and SWAPGROUP. Other names are assumed to be user-defined attributes to be added to the pin.
attr_value :=	attribute or property value

For PINTYPE, the values for attr\_value are:

UNDEFINED  
 OUTPUT  
 INPUT  
 BI-DIRECTIONAL  
 OPEN COLLECTOR  
 OR-TIEABLE  
 TRI-STATE  
 TERMINATOR  
 POWER  
 GROUND  
 OPEN EMITTER  
 NO CONNECT  
 SOURCE  
 LOAD  
 PASSIVE  
 PCB CONNECT

ADDUNGATEDPINS, pin\_type, net, pin\_name [ , pin\_name ... ]

Add one or more ungated power/ground pins to a part.

pin\_type := see list of pintypes under ADDPINATTR  
net\_name := name of the net to apply to the pins  
pin\_name := identifies the pin to add

ALLOWADDPINS, bool  
Specifies whether the ADDPINATTR command should add new (ungated) pins for any pin names specified that don't already exist on the part. Default value is True.

AUTONAME,separator,stem,attr\_name[,attr\_name...]  
Define the rules for auto-naming parts based on their attribute values.  
separator := text to separate each part of name  
stem := text to place at start of each name  
attr\_name := name of attribute holding value to add to name  
To stop autonaming (i.e. to revert to 'manually' named parts), include an AUTONAME command with NONE as the only parameter, like this:  
AUTONAME,NONE

AUTOPART,attr\_name=attr\_value [, attr\_name=attr\_value]  
Create an auto-named part (using the name rules specified by the preceding AUTONAME command), adding the given attributes to the part as it is created.

CONNECTOR, bool [ , sym\_name ]  
Specifies whether parts created using PART command are connector parts. If True, sym\_name should be included to specify the name of the appropriate schematic symbol. Default value is False.

COPYPART, name, newname [ , description [ , attr\_name = attr\_value ... ]  
Creates a copy of an existing part to a new name.  
name := name of existing part  
newname := name of new part  
description := part description (optional)  
attr\_name = attr\_value := one or more pairs of attribute settings

DELATTR, attr\_name  
Deletes the named attribute from the current part (as located using the FINDPART command).

MAKEGROUP,name [ , name ... ]  
Groups all the named parts together into a single part group. If you name a part that is already in a group, then all parts listed for this command will be added to that group. Parts with different pincounts will not be added to the group, and neither will parts that already belong to a second group if you first name a part that is already in a different group.  
name := name of existing part

NAMESTEM,name  
Sets the default component name stem to be used when adding parts.

PARTGROUP,group\_name  
Sets the name of the group to which parts will belong. This name will be used for all subsequent parts that are added using any of the commands that create parts.

To reset to the default behaviour (each part in its own group), use NONE for group\_name.

#### PARTREP, rep\_name

Sets the name of the current Part Representation. As new parts are created they will have this name applied to their first representation.

Also sets the ‘context’ in which other part commands operate when manipulating existing parts found using the FINDPART command. When an existing part is identified using FINDPART, various commands such as ADDGATE will operate on the named part representation.

To reset to the default behaviour (no specified part representation), use NONE for the rep\_name. Then all commands will operate on the default (or only) part representation.

#### SETDESCRIPTION, name, string

Sets the description of the specified part to the given string.

name := part name

#### SETFOOTPRINT, name, footprint\_name [ , footprint\_name ... ]

Replaces the list of footprints referenced by the specified part. Any existing footprint names on the part will be removed.

name := part name

footprint\_name ::= name of pcb footprint

#### SETGATE, name, gate\_name, pin\_name, logic\_name [ , pin\_name, logic\_name ... ]

Replaces the contents of the specified gate on an existing part. The pin name and logic name pairs are applied in schematic symbol pin order, i.e. the first pair apply to symbol pin 1, the second pair to pin 2, etc.

name := part name

gate\_name ::= name of gate (e.g. A, B, C)

pin\_name ::= pin name to apply to gate pin

logic\_name ::= logic name to apply to gate pin

#### SETGATEPINS, name, ...

Same as SETGATE but doesn't remove existing pin details.

#### SETGATESYMBOLS, name, gate\_name, sym\_name [ , gate\_name... ]

Replaces the symbol(s) used by the specified part.

name := part name

gate\_name := name of gate (e.g. A, B, C)

sym\_name ::= symbol name

#### SETSTEM, name, string

Changes the default component name stem of the specified part to the given string.

name := part name

#### SETSSEMBOL, [name,] sym\_name

Changes the symbol used by the specified part (or if name not supplied then the current part as found by FINDPART) to the given symbol.. This command can be applied to normal or connector parts.

name := part name

sym\_name ::= symbol name

++

When this command is added to the end of a line, the line is "joined" to the following line to form a single command. This allows very long commands to be split across multiple lines in the input file to make it easier to read. See the Part section of the Appendix A for an example of how to use this command.

## Appendix A. Sample Files

### Symbol Files

FORMAT,SGF,1	
TYPE,RECT	Rectangular type
UNITS,1,1,2	
LINESTYLE,Normal,8	
PADSTYLE,Cross	Use a standard 'cross'
PADSHAPE,Cross,	for the terminals
PADSIZE,60	
PADDIM3,5	
CLKPIN,30	Size of clock,
POLPIN,40	polarity
INVPIN,60	and inverter markers
NAMEPOS,0	
SPICENAMEPOS,0	
DISTPINS,200	
SYMWIDTH,1200	
LEGLEN,200	
LOGICNAMES,Y	
NUMBERSOUTSIDE,Y	
LEFTPINS,10	10 pins on left side
RIGHTPINS,8	8 on right
TOPPINS,0	With none on top
BOTTOMPINS,0	or bottom
LEFTPINORDER,1	Make sure they're ordered
LEFTPINDIRUP,N	in the right direction
RIGHTPINORDER,2	
RIGHTPINDIRUP,Y	
MARKPIN,1,CLK	Put clock marker on first pin
MARKPIN,10,INV	And invert the 10 <sup>th</sup> one
NAME,ATMEL20	
LEFTPINS,12	
RIGHTPINS,10	
MARKPIN,1,CLK	
NAME,ATMEL24	

### Footprint Files

#### Through-hole DIP

FORMAT,FGF,1	Always first command
UNITS,1,1,2	Thou
TYPE,DIP	
PADLAYER,<Through Board>	Make pads through-hole
DRILL,32	Drill size 32 thou
PADSHAPE,ROUND	Round pads
PAD1SHAPE,Y,SQUARE	Pad 1 is square instead
PADSIZE,55	55 thou pad diameter
PADSTYLE,Pad1	Call the pad style "Pad1"
ORIGIN,1	Symbol origin at pin 1

## 28 Examples

---

```
SILKCREATE,Y          Create silkscreen
SILKNOTCH,Y          Include a notch
SILKDOT,N            But no dot
SILKGAP,25           25 thou outside pads
SILKNOTCHSIZE,25     Size of notch
SILKLAYER,"Top Silkscreen" Name of layer for silkscreen

PLACECREATE,Y        Also create placement shape
PLACEGAP,25

;-----
; Standard DIPS

PADPITCH,100         100 thou between pads
ROWPITCH,300        300 thou across rows

PADCOUNT,6          6 pads
NAME,DIP6            Generate "DIP6" in library
PADCOUNT,8          8 pads
NAME,DIP8            Generate "DIP8"
                    Etc

PADCOUNT,14
NAME,DIP14
PADCOUNT,16
NAME,DIP16
PADCOUNT,18
NAME,DIP18

ROWPITCH,600        Now change row pitch
                    Other params stay the same
PADCOUNT,14
NAME,DIP14W
PADCOUNT,16
NAME,DIP16W
PADCOUNT,18
NAME,DIP18W
```

### Surface-mount PLCC

```
FORMAT,FGF,1        Always first command
UNITS,3,1,2         Units are mm
PADLAYER,<Top Side> Pads on top side only
DRILL,0             No drill
ORIGIN,0            Origin in footprint centre

SILKCREATE,Y        Create silkscreen
SILKMITRE,Y        With a mitred corner
SILKNOTCH,Y
SILKDOT,N
SILKGAP,1          1mm gap

PLACECREATE,Y        Also create placement shape
PLACEGAP,1.1        Slightly larger

;-----
; PLCC
TYPE,QUAD           Quad components
PADDIM3,0.1        0.1mm rounded pad corners
PADSHAPE,ROUNDRECT
PINORDER,1         Number pins anti-clockwise
PADPITCH,1.27      1.27 mm between pads
PADSIZE,0.55       Pad size 0.55mm
PADLENGTH,2.2      And length 2.2mm
```

```

PADCOUNT,20
ROWPITCH,8.6
NAME,PLCC20
PADCOUNT,28
ROWPITCH,11.2
NAME,PLCC28
PADCOUNT,44
ROWPITCH,16.2
NAME,PLCC44
PADCOUNT,52
ROWPITCH,18.8
NAME,PLCC52

```

20-pin footprint  
8.6mm across rows  
Generate PLCC20  
etc...

### Use of ADDPAD command

```

FORMAT,FGF,1
TYPE,DIP
UNITS,3,1,2
ORIGIN,1
SILKCREATE,Y
SILKNOTCH,Y
SILKDOT,N
SILKGAP,0.5
PADSHAPE,ROUND
PADSIZE,1.5
PADLAYER,<Through Board>
DRILL,0.7

ADDPAD,4,4
ADDPAD,0,0
PLACEBOX,-2,-2,9,5
NAME,ODD2

```

## Parts Files

### Normal use to create new parts

```

FORMAT,PGF,1

; create three 'normal' capacitor parts
NEWPART,C0402,Capacitor,Ceramic Surface Mount,C,C0402,2
NEWPART,C0805,Capacitor,Ceramic Surface Mount,C,C0805,2
NEWPART,C1206,Capacitor,Ceramic Surface Mount,C,C1206,2

; create new part group with parts auto-named using attributes
PARTGROUP,CERCAP
AUTONAME,"-/-",C,Value,L
NEWPART,C,Capacitor,Generic,C,C1206,2
ADDATTR,Value,1.0k
AUTOPART,Value=2.2k,L=1.6
AUTOPART,Value=3.3k,L=1.6
AUTOPART,Value=4.7k,L=1.6
AUTONAME,NONE
PARTGROUP,NONE

; create a part with specific pin name order and some pin
attributes
NAMESTEM,RX
NEWPART,RX,,ADD,DIP6,6,1,3,5,2,4,6
ADDATTR,VALUE,2
ADDPINATTR,1,NETNAME=VSS,LOGICNAME=VSS,PINTYPE=POWER

```

## 30 Examples

---

```
ADDPINATTR, 2, LOGICNAME=CLK, PINTYPE=SOURCE
ADDPINATTR, 3, PINTYPE=Tri-State
ADDPINATTR, 2, SWAPGROUP=1
ADDPINATTR, 4, SWAPGROUP=1
ADDPINATTR, 6, SWAPGROUP=1
ADDPINATTR, 5, MARGIN=0.4, RESET=Y

; Create a multi-gate part with a power gate
PART, MY74, , , DIP14, 14
ADDGATE, AND2, 3, 1, 2, 3
ADDGATE, AND2, 3, 4, 5, 6
ADDGATE, AND2, 3, 9, 8, 10
ADDGATE, AND2, 3, 12, 11, 13
ADDGATE, PWR2, 2, 7, 14
ADDPINATTR, 7, LOGICNAME=GND, PINTYPE=GROUND, NETNAME=GND
ADDPINATTR, 14, LOGICNAME=VCC, PINTYPE=POWER, NETNAME=VCC
```

### Use of ADDPINATTR, ADDUNGATEDPINS and ++ commands

```
PART, EP600IPC-45, CLASSIC EP, Altera, DIP24, 24
ADDATTR, Category, FPGA/CLASSIC EP
ADDGATE, ALTERA-1, 22, 1, 13, 23, 14, 2, 11, 3, 4, ++
5, 6, 7, 8, 9, 10, 22, 21, 20, 19, 18, 17, 16, 15, 1, 22, ++
1, 13, 23, 14, 2, 11, 3, 4, 5, 6, 7, 8, 9, 10, 22, 21, 20, 19, ++
18, 17, 16, 15, 1, 22, 1, 13, 23, 14, 2, 11, 3, 4, 5, 6, 7, 8, 9, 10, ++
22, 21, 20, 19, 18, 17, 16, 11, 22, 1, 13, 23, 14, 2, 11, 3, 4, 5, 6, ++
7, 8, 9, 10, 22, 21, 20, 19, 18, 17, 16, 15

ADDPINATTR, 1, LOGICNAME=CLK1, PINTYPE=INPUT
ADDPINATTR, 13, LOGICNAME=CLK2, PINTYPE=LOAD
ADDPINATTR, 23, LOGICNAME=IN, PINTYPE=LOAD
ADDPINATTR, 14, LOGICNAME=IN, PINTYPE=LOAD
ADDPINATTR, 2, LOGICNAME=IN, PINTYPE=LOAD
ADDPINATTR, 11, LOGICNAME=IN, PINTYPE=LOAD
ADDUNGATEDPINS, GROUND, GND, 12
ADDUNGATEDPINS, POWER, VCC, 24
ADDPINATTR, *, LOGICNAME=I/O, PINTYPE=BI-DIRECTIONAL
```

## Appendix B. Change History

### Issue 30-Apr-09 [Pulsonix 6.0]

Show how to add comments to the file using # as the first character on the line.

Correction to the NEWPART command on a part, to show the missing optional field for the number of Symbol pins.

Handling of multiply-mapped pins in NEWPART, ADDGATE and ADDPARTREP commands.

Change of default handling for part grouping for format 3 part files, see page 21.

Addition of the following commands:

ASSOCPART : create a new Associated Part.

COPYPART : make a copy of an existing part under a new name.

MAKEGROUP : collect existing parts together into a part group.

PARTGROUP : collect new parts together into a part group.

SETGATESYMBOLS : set the list of symbol names to apply to a gate.

### Issue 20-Oct-08 [Pulsonix 5.1]

New SETGATESYMBOLS command on a part, allowing the addition of alternate symbol names to an existing gate definition.

### Issue 08-May-08 [Pulsonix 5.0]

ADDATTR command on a part can now add 'built-in' attributes such as Family, Height and Hyperlink.

PADSHAPE commands now recognise a larger range of available pad shapes.

### Issue 27-Mar-08

SETFOOTPRINT command can now accept multiple footprint names, to specify a list of alternate footprints for a part. First footprint name is used as the default footprint for the part.

### Issue 18-Feb-04

Changes added for Pulsonix version 3.0.

Additional commands for generating new parts: ADDUNGATEDPINS, ALLOWADDPINS, CONNECTOR,

## 32 Change History

---

Additional commands for amending existing parts: DELATTR, SETDESCRIPTION, SETFOOTPRINT, SETGATE, SETSTEM, SETSYMBOL.

Part command line continuation suffix "++"

### Issue 01-Sep-03

Changes for handling symbol integration files, added for Pulsonix version 2.1.

### Issue 02-June-03

Addition of command for finding Parts (FINDPART)

### Issue 26-Feb-03

Addition of commands for bond pads and wires (ADDBONDPAD, ADDBONDPADSET, BONDPADDRILL, BONDPADLAYER, BONDPADLENGTH, BONDPADSHAPE, BONDPADSIZE, BONDPADSTYLE, WIRELAYER, WIRESIZE, WIRESTYLE).

Addition of command ADDPADSET for adding multiple 'arrays' of pads in specific positions.

### Issue 09-Sep-02

Addition of PART and ADDGATE commands to facilitate multi-gate parts.

### Issue 21-Aug-02

Addition of command ADDPINATTR for part pin attributes and properties.

Addition of command PARTGROUP for grouping parts.

Addition of commands AUTONAME and AUTOPART for creating auto-named parts.

Addition of command PLACEBOX for user-defined placement shape in footprint.

Changes to sample listings for above commands.

### Issue 06-Aug-02

Values shown for PADLAYER changed from <All>, <Top>, <Bottom> to <Through Board>, <Top Side> and <Bottom Side> respectively.

Note that ADDPAD command over-rides default pad pattern for footprint.

Addition of sample footprint commands for use of ADDPAD command.

Change to ADDPART command to match actual program behaviour. Copies details from previously added part, does not add to same part group.

---

# Index

## C

Change History, 31

Comment command (#), 9, 13, 21

## K

### Keywords

#, 9, 13, 21

++, 26, 30

ADDATTR, 22

ADDBONDPAD, 13, 14

ADDBONDPADSET, 14

ADDGATE, 22, 23

ADDPAD, 14, 18, 29, 32

ADDPADSET, 14

ADDPART, 22

ADDPINATTR, 23, 30

ADDUNGATEDPINS, 23, 30

ALLOWADDPINS, 24

ASSOCPART, 21

AUTONAME, 24

AUTOPART, 24

AXIALLEGS, 18

BONDPADDRILL, 14

BONDPADLAYER, 15

BONDPADLENGTH, 15

BONDPADSHAPE, 15

BONDPADSIZE, 15

BONDPADSTYLE, 15

BOTTOMPINDIRLEFT, 10

BOTTOMPINORDER, 10

BOTTOMPINS, 10

BOXLENGTH, 18

BOXROUND, 18

BOXWIDTH, 18

CLKPIN, 10

COLCOUNT, 18

CONNECTOR, 24

COPYPART, 24

DELATTR, 24

DIAMETER, 18

DRILL, 15

FILE, 9, 13, 21

FINDPART, 21

FIRSTPIN, 15

FORMAT, 9, 13, 21

HORIZPADCOUNT, 18

HORIZROWPITCH, 18

INVPIN, 10

LEFTPINDIRUP, 10

LEFTPINORDER, 10

LEFTPINS, 10

LEGLEN, 10

MARKPIN, 10

NAME, 9, 15

NAMEPOS, 10, 15

NAMESTEM, 24

NUMBERSOUTSIDE, 10

ORIGIN, 10, 16

PAD1SHAPE, 16

PADCOUNT, 16

PADDIM3, 11, 16

PADFILLED, 11

PADLAYER, 16, 32

PADLENGTH, 11, 16

PADPITCH, 11, 16

PADSHAPE, 11, 16

PADSIZE, 11, 16

PADSTYLE, 11, 16

PART, 22

PARTGROUP, 24

PINORDER, 16

PINTYPE, 23

PLACEBOX, 17

PLACECREATE, 17

PLACEGAP, 17

PLACEISAREA, 17

PLACELAYER, 17

POLPIN, 11

RADIUS, 19

RIGHTPINDIRUP, 11

RIGHTPINORDER, 11

RIGHTPINS, 11

ROWCOUNT, 18

ROWPITCH, 17

SEGLEFTPINS, 12

SEGMENTS, 12

SEGRIGHTPINS, 12  
SETDESCRIPTION, 25  
SETFOOTPRINT, 25  
SETGATE, 25  
SETGATESYMBOLS, 25  
SETSTEM, 25  
SETSSEMBOL, 25  
SHOWLOGICNAMES, 11  
SHOWPINNAMES, 11, 17  
SILKCREATE, 17  
SILKDOT, 17  
SILKGAP, 17  
SILKLAYER, 17  
SILKMITRE, 17  
SILKMITRESIZE, 17  
SILKNOTCH, 17  
SILKNOTCHSIZE, 17  
SPICENAMEPOS, 10  
STAGGERODD, 18  
STAGGERPITCH, 18  
STARTANGLE, 19  
SYMWIDTH, 11  
TABANGLE, 19  
TABSIZe, 19

TOPPINDIRLEFT, 11  
TOPPINORDER, 11  
TOPPINS, 11  
TYPE, 9, 13  
UNITS, 9, 13  
VERTPADCOUNT, 18  
VERTROWPITCH, 18  
WIRELAYER, 17  
WIRESIZE, 18

### **P**

Parameter types  
  angle, 19  
  bool, 19  
  count, 19  
  size, 19  
  x, 19  
  y, 19

### **S**

Sample files  
  Footprints, 27  
  Parts, 29  
  Symbols, 27